

Channels/Mixes					Inputs/Outputs								
Channels			Mixes		Sources				Output				
#	ST	Name	Mix	ST	Name	AES	#	Source	Mic	48v	AES	#	Source
1		Albin	Bus 1		Stage Mon	Local	1	AT 17			Local	1	
2		Georges	Bus 2				2	AT 18				2	
3		Jean-Michel	Bus 3				3	Announce				3	
4		Jacob	Bus 4				4					4	
5		Edouard	Bus 5		Drum Bus (?)		5					5	
6		Marie	Bus 6		Cagelles		6					6	
7		Anne	Bus 7		Qlab		7					7	
8		Jacq	Bus 8		Dennons		8	Talkback				8	
9		Francis	Bus 9		Drums	AUX Inputs	1	Bluetooth			AUX Outputs	1	
10		Hanna	Bus 10		Talkbacks		2					2	
11		Bitelle	Bus 11		Reed 1		3	Local Stereo				3	
12		Mercedes	Bus 12		Reed 2		4					4	
13		Phaedra	Bus 13		FX 1		5					5	
14		Babette	Bus 14		FX 2		6					6	
15		Chantal	Bus 15		FX 3		7					7	
16		Drop Mics	Bus 16		FX 4		8					8	
17			Matrix 1		Backstage	USB	1				USB	1	
18			Matrix 2				2					2	
19			Matrix 3				3					3	
20			Matrix 4				4					4	
21			Matrix 5				5					5	
22			Matrix 6				6					6	
23			Matrix 7				7					7	
24			Matrix 8				8					8	
25		Keys 1	Main 1		Mains	AES A	1	SL 1			AES A	1	Mon 1
26		Keys 2	Main 2		Deck L/R		2	SL 2				2	Mon 2
27		Reed 1 UP	Main 3		Surr L/R		3	SL 3				3	Mon 3
28		Reed 1 DN	Main 4		Surr Center		4	SL 4				4	Mon 4
29		Reed 2 UP					5	SL 5				5	Hanging L
30		Reed 2 DN					6	SL 6				6	Hanging R
31		Trumpet					7	SL 7				7	Main L
32		Trombone					8	SL 8				8	Main R
33		Bass	DCA 1		Cue Controlled	AES A	9	SR 9			AES A	9	
34		Kick in	DCA 2				10	SR 10				10	
35		Kick Out	DCA 3				11	SR 11				11	
36		Snare	DCA 4				12	SR 12				12	
37		Tom	DCA 5				13	SR 13				13	
38		FL Tom	DCA 6				14	SR 14				14	Surr L
39		Overheads	DCA 7				15	SR 15				15	Surr R
40		Conductor	DCA 8				16	SR 16				16	Surr C
41		Qlab 1/2	DCA 9		Muted Cast	AES B	17	Front 17			AES B	1	
42		Qlab 3/4	DCA 10		Orch		18	Front 18				2	
43		Qlab 5/6	DCA 11		Qlab		19	Front 19				3	
44		Qlab 7/8	DCA 12				20	Front 20				4	
45		Bluetooth	DCA 13				21					5	
46		Booth Stereo	DCA 14				22					6	
47		Wireless	DCA 15				23	Hanging L				7	
48		Talkback	DCA 16				24	Hanging R				8	

Actor Mic Assignments				
#	Pack Type	Character	Actor	Lead Type
1	Shure	Albin		WL93
2	Shure	Georges	Esra	Short Beige
3	Shure	Jean-Michel	Justin	Short Beige
4	Shure	Jacob		WL93
5	Shure	Hanna		Pink WL93
6	Shure	Chantal		WL93
7	Shure	Anne		Short Beige
8	Shure	Backup Pack		
9	AT	Jacq		Short Black
10	AT	Fancis		Short Beige
11	AT	Edouard		Short Beige
12	AT	Marie		Short Beige
13	AT	Bitelle		hix wig
14	AT	Mercedes		hix wig
15	AT	Pheadra		hix wig
16	AT	Babette		hix wig
17	AT	Spare		
18	AT	Backup Pack		

25					1
26					2
27					3
28					4
29					5
30					6
31	Booth Stereo				7
32					8
1	Shure 1				9
2	Shure 2				10
3	Shure 3				11
4	Shure 4				12
5	Shure 5				13
6	Shure 6				14
7	Shure 7				15
8	Shure 8				16
9	AT 9				
10	AT 10				
11	AT 11				
12	AT 12				
13	AT 13				
14	AT 14				
15	AT 15				
16	AT 16				
1	Keys 1	PCDI			
2					
3	Keys 2	Radial DI			
4					
5	Reed 1 Up	Sm137			
6	Reed 1 Down	Sm137			
7	Reed 2 Up	Sm137			
8	Reed 2 Down	Sm137			
9	Conductor	Sm58s			
10	Bass	Sm137			
11					
12					
13					
14					
15					
16					
17	Trumpet	Sm57			
18	Trombone	Sm57			
19					
20					
21					
22					
23					
24					
25	Kick In	PGA52			
26	Kick out	Beta 52			
27	Snare	Sm57			

(AES C, outputs 33-48)

Monitors	
P16 Patch	
1	Keys 1
2	Keys 2
3	Reed 1
4	Reed 2
5	Trumpet
6	Trombone
7	Bass
8	Drums
9	Albin
10	Georges
11	Jean
12	Jacob
13	Characters
14	Cagelles
15	QLAB
16	Talkbacks

						28	Tom 1	PGA56	
						29	Tom 2	PGA56	
						30			
						31	Overheads	PGA81	
						32		PGA81	